

# Installation, Commissioning and Servicing Instructions

## Atmospheric Cast Iron Boiler 40kW to 120kW Output

### AUTOMATIC IGNITION CONTROLS

*Standard Draught Diverter  
or  
Low Line Draught Diverter*

## Purewell

Gas Fired  
Modular Boiler Systems

NATURAL GAS  $I_{2H}$   
LPG-PROPANE  $I_{3P}$

#### IMPORTANT NOTE


THESE INSTRUCTIONS MUST BE READ AND UNDERSTOOD BEFORE  
INSTALLING, COMMISSIONING, OPERATING OR SERVICING EQUIPMENT.



BS EN ISO 9001:1994  
Certificate No. FM 10082



**HAMWORTHY**  
heating products



# Customer Services

## ■ TECHNICAL ENQUIRIES

☎ 01202 662527 / 662528

To supplement the detailed technical brochures, technical advice on the application and use of products in the Hamworthy Heating range is available from our technical team in Poole and our accredited agents.

## ■ SITE ASSEMBLY

☎ 01202 662555

Specialist teams are available for on site assembly of the full range of Hamworthy boilers (excluding Lulworth). Boiler sections for site assembly must be positioned within the boiler house prior to the arrival of the assembly team and provide sufficient space for safe working. Handling sections into boiler houses other than at ground level may be subject to additional charges.

The normal assembly price does not include for the fitting of boiler casings or the burner, however this can be carried out at the time of build at additional cost.

Providing the facilities are available on site, a hydraulic test will be carried out within the terms of BS779. Upon completion a certificate of assembly and test will be issued.

## ■ COMMISSIONING

☎ 01202 662555

Commissioning of equipment by Hamworthy Heating's own engineers, accredited agents or specialist sub-contractors will ensure that the equipment is operating safely and efficiently. Hamworthy commissioning reports provide a detailed record of the original status of the plant, which is essential for future routine maintenance and trouble free operation.

Standard warranty terms provide for the free of charge replacement of defective parts, but does not include labour. When the equipment is commissioned and routinely maintained by Hamworthy Heating under a Service Maintenance Agreement then the warranty terms will cover both parts and labour.

## ■ MAINTENANCE AGREEMENTS

☎ 01202 662555

Regular routine servicing by Hamworthy Heating's engineers ensures trouble free operation and optimum efficiency. The frequency of visits required is variable, dependent upon the equipment type and usage. Annual service agreements are available on all Hamworthy products to meet individual requirements.

Planned maintenance of equipment by routine servicing reduces operational costs considerably below that associated with repair or breakdown approach.

## ■ BREAKDOWN SERVICE, REPAIR, REPLACEMENT

☎ 01202 662555

Even when the commissioning and routine servicing has been carried out to the highest standard there are always occasions when the unexpected breakdowns occur. Hamworthy provide a rapid response breakdown, repair or replacement service through head office at Poole and accredited agents located throughout the UK.

## ■ SPARE PARTS

☎ 01202 662525

A comprehensive spare parts service is operated from our factory in Poole, providing replacement parts for both current and discontinued products. In some instances spares may be available from accredited agents.

Delivery of parts and components is normally from stock within 7 days. However, a 24 hour delivery service is available for breakdowns and emergencies for the additional cost of the courier. Please contact our spares team, providing details of product type, serial number, model or any other identifying marks or codes to determine part requirements wherever possible.

# **PUREWELL ATMOSPHERIC HOT WATER BOILER FOR HEATING AND DOMESTIC HOT WATER INSTALLATIONS**

## **INSTALLATION, COMMISSIONING AND SERVICING INSTRUCTIONS**

### **AUTOMATIC IGNITION CONTROLS**

*WITH STANDARD DRAUGHT DIVERTER (D/D)  
40,50,60,70,80,95,105 & 120kW models*

*OR WITH LOW LINE DRAUGHT DIVERTER (L/L)  
40,70 & 100kW models*

**NOTE: THESE INSTRUCTIONS SHOULD BE READ AND UNDERSTOOD BEFORE ATTEMPTING TO INSTALL, COMMISSION OR OPERATE THIS UNIT**

**THE PUREWELL BOILER IS INTENDED FOR USE AS A COMMERCIAL APPLIANCE AND IS NOT CERTIFIED FOR USE IN DOMESTIC APPLICATIONS OR HABITABLE AREAS.**

**THIS BOILER IS FOR USE ON GROUP H NATURAL GAS (2ND FAMILY)I<sub>2H</sub> OR LPG-PROPANE (3<sup>RD</sup> FAMILY)I<sub>3P</sub>. PLEASE ENSURE RELEVANT INFORMATION REQUIRED WITHIN DOCUMENT IS FOUND RELATING TO SPECIFIC GAS TO BE FIRED BEFORE FIRING BOILER.**

THIS BOILER COMPLIES WITH ALL RELEVANT EUROPEAN DIRECTIVES.  
EC TYPE CERTIFICATE No. BG/EC-87/93/20.  
PRODUCT IDENTIFICATION No. 87AO20

PUBLICATION NO. 500001035  
ISSUE 'G'  
JANUARY 2000

THIS PAGE LEFT INTENTIONALLY BLANK

# CONTENTS

	<b>PAGE</b>
<b>INDEX</b> .....	iii
<b>1.0 INTRODUCTION</b> .....	1
<b>2.0 TECHNICAL DATA</b> .....	1
2.1 Overall Dimensions	
2.2 Technical Data Table	
<b>3.0 GENERAL REQUIREMENTS</b> .....	1
3.1 Related Documents	
3.2 Feed Water Quality	
3.3 Adequate Water Flow	
3.4 Time Clock Control	
3.5 Minimum System Pressure	
<b>4.0 LOCATION</b> .....	4
<b>5.0 GAS SUPPLY</b> .....	4
5.1 Service Pipes	
5.2 Meters	
5.3 Gas Supply Pipes	
5.4 Boosted Supplies	
5.5 Boiler House Control Valve	
5.6 Boiler Gas System Leak Check	
<b>6.0 FLUE SYSTEM</b> .....	5
6.1 General Requirements	
6.2 Design Waste Gas Volume and Temperature	
6.3 Flue Condensation	
6.4 Materials	
6.5 Disconnection	
6.6 Flue Discharge	
6.7 Surface Temperature	
6.8 Flue System Location	
<b>7.0 AIR SUPPLY</b> .....	9
7.1 Air Supply by Natural Ventilation	
7.2 Air Supply by Mechanical Ventilation	
<b>8.0 WATER CIRCULATION SYSTEM</b> .....	9
8.1 General	
8.2 Pressure Relief Valve (Safety Valve)	
8.3 Open Vent Pipe and Cold Feed Pipe	
8.4 Altitude Gauge (Water Pressure Gauge)	
8.5 Thermometer	
8.6 Drain Taps	
8.7 Circulating Pump	
8.8 Minimum Water Flow Rates	
8.9 Waterside Pressure Drop	
8.10 Control Schemes	
8.11 Unvented Pressurised Systems	
8.12 Modular Boiler Control Schemes	

<b>9.0 ELECTRICAL SUPPLY</b> .....	8
9.1 Site Wiring	
<b>10.0 INSTALLATION OF BOILERS</b> .....	9
10.1 General	
10.2 Heat Exchanger Insulation Fitting Instructions	
10.3 Gas pipe Fitting Instructions	
10.4 Connection of Boilers to the Flue System	
10.5 Gas Connection	
10.6 Water Connections	
10.7 Casing and Controls Assembly	
<b>11.0 COMMISSIONING AND TESTING</b> .....	14
11.1 Electrical Installation	
11.2 Gas Installation	
11.3 Water Circulation System	
11.4 Commissioning the Boiler	
11.5 Boiler Checks Prior to Lighting	
11.6 Gas Pressure Adjustment and Combustion Checks	
11.7 Temperature Limiter (Limit Thermostat)	
11.8 Safety Checks	
11.9 User's Instructions	
<b>12.0 FAULT FINDING</b> .....	16
12.1 Safety Features Summary	
12.2 Fault Finding Procedures	
12.3 Possible Causes of Boiler Lockout	
<b>13.0 SERVICING</b> .....	16
<b>14.0 REPLACEMENT OF FAILED COMPONENTS</b> .....	17
<b>15.0 RECOMMENDED SPARES</b> .....	19
<b>APPENDIX 'A' - INFORMATION RELATING TO PROPANE FIRING</b> .....	32

<b>FIGURES</b>	<b>PAGE</b>	
Figure No. 1	Performance and General Data .....	2
Figure No. 2	Recommended/minimum water flow rates.....	3
Figure No. 3	Gas valve integrity check.....	5
Figure No. 4	Mechanical ventilation flow rates.....	6
Figure No. 5	Heat Exchanger Insulation Fitting Instructions.....	10
Figure No. 6	Gas Pipe Fitting Instructions.....	10/11
Figure No. 7	Enclosure assembly details.....	12/13
Figure No. 8	Boiler installation typical layout. Vented and Un-vented boilers.	20
Figure No. 9	Overall dimensions of boiler and recommended clearances ....	21
Figure No. 10	Front assembly showing general layout .....	22
Figure No. 11	Maximum gas flows through pipes .....	23
Figure No. 12	Site wiring details.....	24
Figure No. 13	Typical standard boiler wiring diagram.....	25
Figure No. 13a	Wiring Diagram fitted with Pektron 0459 Series Igniter.....	26
Figure No. 14	Diagram of electrode assembly.....	27
Figure No. 15	Diagram of various gas valves fitted.....	28
Figure No. 16	Diagram of double gas valve layout.....	29
Figure No. 17	General fault finding.....	30/31

## **1.0 INTRODUCTION**

**1.1** A competent person holding 'CORGI' registration or equivalent must install this boiler. All installations **MUST** conform to the relevant Gas Safety and Building Regulations. Health & Safety requirements must also be taken into account when installing any equipment. Failure to comply with the above may lead to Prosecution.

**1.2** These instructions are for Group H Natural Gas (2nd Family) and LPG-Propane (3rd Family). The information relative to propane firing is to be found in Appendix 'A'. Boilers **MUST NOT** use gas other than for which they were designed and made for.

**1.3** The Purewell is an atmospheric, gas fired boiler manufactured from horizontal cast iron sections, nipped at alternate ends. These sections are mounted on a fabricated mild steel basket assembly, which houses the burner bar and igniter assemblies. A unique radiant baffle is fitted beneath the burner bars, protecting the floor below by reducing heat lost from the boiler.

The standard version of the Purewell boiler is designed to be connected to the flue via a specifically designed draught diverter. This diverter **MUST** be fitted into the spigot on top of the heat exchanger as supplied. **NO** modification or variance is permitted as this may change operational characteristics. Flue outlets from more than one boiler may be connected together to form a header.

Low Line versions have an in-built draught diverter and can therefore be connected direct to a header assembly via a suitable flue pipe.

**1.4** If the boiler is to be connected to an un-vented (pressurised) heating system, care must be taken to ensure all extra safety requirements are met and that the relevant interlocks will shut down the boiler(s) should a high or low pressure fault occur.

The pressurisation unit must also incorporate a low level water switch, which protects the water pumps, and will directly or indirectly shut down the boiler plant should a low water condition occur.

Consideration should also be given to the maximum working pressure of the boiler as given in **Section 2: TECHNICAL DATA**. Consult Hamworthy Heating Technical Department for help or assistance if in doubt.

**1.5** The Purewell boiler is not suitable for direct connection to domestic hot water supplies or gravity fed heating systems.

**1.6** The Purewell boiler can be installed with either reverse return water flow layout or with single pipe header layout. See Figure No. 8 for typical schematic layout.

Hamworthy Heating can supply a pre-designed arrangement of components, which will produce a

"reverse-return" assembly. Please contact Hamworthy Heating for information.

**1.7** It is good practice in all heating installations to use some form of water treatment to reduce formation of lime scale and black iron oxide sludge. The high efficiencies produced by the Purewell Boiler can easily be reduced by lime scale formation. If a pressurised unit is used, it is prudent to include an hours run meter to give an indication of pump running time and hence raw water make-up. Any leaks should be attended to as soon as possible to avoid calcium salt build up within the boiler's waterways.

## **2.0 TECHNICAL DATA**

**2.1** Overall dimensions are shown in Figure No. 9. Both single and multi boiler arrangements are shown.

The Purewell boiler can be installed as a single unit or in modular form where a 'multi' casing reduces required floor area. Each boiler has an independent door for access to the controls and other working components.

It is recommended that a maximum of 6 boilers can be positioned on 533mm (21") centres if required. Larger numbers should be split into two or more banks with 150mm (6") between each bank. **NOTE!** When installing modular units on 533mm (21") centres, the casing support rail or spacing plates should be fitted between each boiler before bolting together. See **Section 10.1: General Installation of Boilers Ref.:** - spacing plates for further information.

**2.2** General Information and Technical Data relating to Natural Gas is shown in Figure No. 1.

Technical data relating to propane firing can be found in Appendix 'A'.

**2.3 Screw threads:** All screw threads used in the Purewell boiler conform to the following: -

**ISO 7/1** or **ISO 228/1** for pipe threads where applicable.

**ISO 262** for all general screw threads.

### 3.0 GENERAL REQUIREMENTS

#### 3.1 Related Documents.

#### Gas Safety Installations and Use Regulations 1994, (As amended).

It is law that competent persons in accordance with the above regulations install all gas appliances. Failure to install appliances correctly

could lead to prosecution. It is in your own interest, and that of safety, to ensure that this law is complied with.

The installation of the boiler **MUST** be in accordance with the relevant requirements of the IEE Regulations and the byelaws of the local water undertaking.

Figure No. 1 - Performance and General Data Information

GENERAL DATA	40	50	60	70	80	95	100	105	120
Boiler input kW (Gross)	49.3	63.4	74.5	88.4	101	120	126	132	150
Boiler input kW (Nett)	44.4	57.1	67.1	79.6	90.9	108.5	113.6	118.8	135
Boiler output kW	40	50	60	70	80	95	100	105	120
Gas flow rate m <sup>3</sup> /h.	4.73	5.92	7.1	8.27	9.44	11.19	11.8	12.36	14.1
Gas manifold press. mbar.	13.4	12.5	11.9	11.0	9.5	11.5	10.2	11.2	11.0
Start (low fire) gas manifold press. mbar.	9.0	5.0	3.5	2.0	1.5	1.5	1.5	1.5	1.2
<b>FLUE DATA</b>									
Nominal flue Dia. D/D	206	206	206	206	206	256	-	256	256
Nominal Flue Dia. L/L	206	-	-	206	-	-	256	-	-
Approx. flue gas temp. C	190	200	190	220	230	200	205	215	205
Approx. flue gas vol. @ 9% CO <sub>2</sub> & 100°C. m <sup>3</sup> /hr *	73.8	92.4	110.8	129.1	147.3	174.6	184.1	192.9	220
<b>GAS DATA</b>									
Nominal gas inlet press.	----- 20 mbar -----								
Maximum gas inlet press.	----- 25 mbar -----								
Injector marking/Dia. mm.	2.7	3.1	3.4	3.75	4.2	3.9	4.1	4.1	4.4
No. of Burner bars/Injectors	----- 4 -----					----- 5 -----			
Gas inlet connection	----- R <sup>3</sup> / <sub>4</sub> " -----					----- R 1" -----			
<b>WATER DATA</b>									
Water connections	Flow Rc 2"					Return Rc 2"			
Loss mbar @ 15°C ΔT	2.75	4.31	8.63	11.57	14.9	22.55	25	27.45	47.06
Maximum water pressure	----- 6 barg -----								
Water content litres	30	30	37.1	37.1	37.1	44.2	44.2	44.2	51.3
Litres/sec. @ 11°C ΔT	0.87	1.08	1.30	1.52	1.74	2.06	2.17	2.28	2.6
Litres/sec. @ 15°C ΔT	0.64	0.80	0.95	1.12	1.27	1.51	1.59	1.67	1.91
Litres/sec. @ 22°C ΔT	0.43	0.54	0.65	0.76	0.87	1.03	1.08	1.14	1.3
<b>ELECTRICAL DATA</b>									
Normal Supply Voltage	----- 230 V AC 50 Hz 1 ph -----								
Current Requirements	----- < 1 Ampere -----								
Current Requirements (Pump kit fitted)	1.54 Amperes (25-80)					0.93 Amperes (36-50F)			

\* NOTE! Flue gas volumes are based on a gross flue gas temperature of 100°C at 1013mbar. This is considered to be the predicted temperature of the products in the secondary flue downstream of the draught diverter.

Related Documents - cont.

The installation should also be in accordance with any relevant requirements of the local gas region and local authority and the relevant recommendations of the following documents: -

### British Standards

**BS 7074:** Application, selection and installation of expansion vessels and ancillary equipment for sealed water systems. Part 2: Code of practice for low and medium hot water systems.

**BS 6891:** Installation of low-pressure gas pipework of up to 28mm in domestic premises. (For larger installations see **IM/2**, **IM/5** and **IM/16** below.)

**BS 6644:** Installation of Gas Fired Hot Water Boilers - 60kW to 2MW.

**BS 6700:** Design, installation, testing and maintenance of services supplying water for domestic use.

**BS 6880: Part 1, 2 & 3:** Code of practice for low temperature hot water heating systems of output greater than 45kW.

**BS EN 60335, Part 1.** Safety of Household & Similar Electrical Appliances. **BS 3456, Part 201:** Electrical Standards.

**Figure No. 2 - Flow-rate/Pressure Drop Table**

Model	40	50	60	70	80	95	100	105	120
Flow @ 11°C ΔT rise litres/second	0.87	1.08	1.30	1.52	1.74	2.06	2.17	2.28	2.60
Resistance mbar	5.1	7.84	15.69	20.59	26.47	37.25	41.12	50	84.31
Flow @ 15°C ΔT rise litres/second	0.64	0.80	0.95	1.12	1.27	1.51	1.59	1.67	1.91
Resistance mbar	2.75	4.31	8.63	11.57	14.9	22.55	25	27.45	47.06
Flow @ 22 °C ΔT rise litres/second	0.43	0.54	0.65	0.76	0.87	1.03	1.08	1.14	1.3
Resistance mbar	1.27	2.06	4.12	5.49	7.06	11.76	12.94	13.23	22.55

### 3.2 Feed water Quality

If the boiler feed water has a high degree of hardness, it is recommended that the water be treated to prevent precipitation of scale or sludge in the boiler water passageways. Details of additives can be obtained from any reliable manufacturer of water treatment products or the local water authority. It should be noted however, that even if the boiler water is of average hardness, not requiring treatment, subsequent draining of the system for repair or constant make-up water due to an undetected leak will cause additional deposits and gradual build-up of scale. It is essential, therefore that leaks are attended to promptly and draining is kept to an absolute minimum.

It is recommended that the system is flushed out at least twice with hot water before any treatment is added. If any doubt exists regarding the

**CP 342:** Centralised hot water supply.  
Part 2: Buildings other than individual dwellings.

### British Gas Publications

**IM/2** Purging procedures for non-domestic gas installations.

**IM/5** Soundness testing procedures for industrial and commercial gas installations.

**IM/11** Flues for commercial and industrial gas fired boilers and air heaters.

**IM/16** Guidance notes on the installation of gas pipework. (Excluding domestic installations of 25mm and below.)

### Health and Safety Executive:-

**Guidance note PM5** - Automatically controlled steam and hot water boilers.

### CIBSE Publications: - "CIBSE Guide"

It is impractical in this document to specify all relevant information, but the following extracts from the above references are emphasized since failure to comply with these requirements will almost certainly result in an unsatisfactory installation.

It is recommended that the system is flushed out at least twice with hot water before any treatment is added. If any doubt exists regarding internal cleanliness of an old system, consideration should be given to the fitting of a coarse filter in the return pipework to the boilers.

### 3.3 Adequate Water Flow

The Hamworthy Purewell boiler is designed as a quick response, low water content unit, to run continuously with maximum reliability. Care should be taken in the initial design and layout having due regard for adequate water flow through the boilers and the influence of the system controls. **NOTE!** The Standards Authority recommend a minimum return temperature of 50°C in all heating systems other than condensing boilers.

Figure No. 2 shows recommended and minimum water flows required. The control system and valves, where fitted, should be regulated to avoid lower flows occurring.

The flow corresponding to 22°C temperature rise across the boiler is the minimum recommended flow at any time. For boiler pressure drop see Figure No. 2.

### 3.4 Time Clock Control

In order to avoid local overheating and progressive calcium deposition at zero flow conditions where boilers are operated from time clocks, provision should be made for a 5 minute circulating pump over-run after the last boiler has ceased firing.

**NOTE!** Time clocks should not interrupt live, neutral or earth connections, see **Section 9.0: ELECTRICAL SUPPLY** for details. See Figure No. 12 for wiring details.

### 3.5 Minimum System Pressure

To comply with guidance note **PM5 (Health and Safety Executive)**, the minimum pressure requirements at the boiler are given below as examples: -

- 1) Single installed boiler running at 82°C flow temperature. Minimum head required is not less than 2 metres or 0.2 bar.
- 2) Single installed boiler running at 95°C flow temperature. Minimum head required = 5.1 metres or 0.5 bar.
- 3) Modular boiler installation running at 82°C flow temperature and 11°C rise across system. Minimum head required = 4.3 metres or 0.42 bar.
- 4) Modular boiler installation running at 82°C flow temperature and 22°C rise across system. Minimum head required = 10.5 metres or 1.03 bar.

See **Section 8.11** for Pressurised Water Systems.

## 4.0 LOCATION

**4.1** (See Figure No. 9 for dimensions/weights and clearances.) The location chosen for the boiler **MUST** permit the provision of a satisfactory flue system and an adequate air supply. The location must also provide adequate space for servicing and air circulation around each unit. This includes any electrical trunking laid along the floor.

Allow adequate space, this should not normally be less than 460 mm. at the rear, for flow and return connections. Also allow at least 460 mm. on one side, the other side must be no less than 150 mm. Allow 610mm (minimum) in front of the boiler for servicing.

The boiler must be installed on a level non-combustible surface that is capable of adequately supporting its weight (when filled with water) and any ancillary equipment.

Any combustible material adjacent to the boiler and the flue system must be so placed or shielded to ensure that its temperature does not exceed 65°C.

Further details regarding boiler location are given in **BS 6644**.

## 5.0 GAS SUPPLY

### 5.1 Service Pipes

The local gas region must be consulted at the installation planning stage in order to establish the availability of an adequate supply of gas. An existing service pipe must not be used without prior consultation with the local gas region.

### 5.2 Meters

A new gas meter will be connected to the service pipe by the local gas region, or a local gas region contractor. An existing meter should be checked, preferably by the gas region, to ensure that it is adequate to deal with the rate of gas supply required.

### 5.3 Gas Supply Pipes

Supply pipes must be fitted in accordance with **BS 6891** or **IM/16** as appropriate. Pipework from the meter to the boiler must be of adequate size. Do not use pipes of a smaller size than the boiler gas connection. The complete installation must be purged and tested for soundness as described in **BS 6891** or **IM/2** and **IM/5** as appropriate.

See Figure No. 11 for recommended gas flows in pipes.

### 5.4 Boosted Supplies

Where it is necessary to employ a gas pressure booster, the controls must include a low-pressure cut-off switch at the booster inlet. The local gas region must be consulted before a gas pressure booster is fitted.

### 5.5 Boiler House Control Valve

A manual valve for boiler house isolation shall be fitted in the gas supply line. It shall be clearly identified and readily accessible for operation, preferably by an exit.

### 5.6 Boiler Gas System Leak Check

Although the boiler receives a gas leak check and gas train component integrity check prior to leaving the factory, transport and installation may cause disturbance to unions, fittings and gas valve assemblies' etc. During commissioning a further test for soundness should be carried out on the boiler gas pipework and components. A procedure guide is given below. Care must be taken not to allow leak detection fluid on or near any electrical parts or connections (If used). See Figure No. 3 - Gas valve/pipework leak check test procedure.

## To Check Valve B


- 1) Turn off the electrical power and gas to the appliance.
- 2) Connect the manometer to gas valve test point.
- 3) With A, B closed open C and monitor manometer over a 2 minute period, a rise indicates a leak on valve B.

## To Check Valve A

- 1) Open C.
- 2) Open B to produce the main gas supply pressure between A and B.
- 3) Close B
- 4) System may be considered sound if over a period of 2 minutes any drop in pressure is less than 0.5 mbar (0.2" wg.).

**NOTE:** Allow a manometer stabilisation period of approximately 1-minute before each 2 minute check period. Following soundness tests close valve B and remove manometer connections and tighten test points.

**Figure No. 3 - Gas Valve leak check procedure**



**Note:** - Main gas supply pressure; G20 – 20mbar  
G31 – 37mbar

## 6.0 FLUE SYSTEM

Detailed recommendations for flue systems are given in **BS 6644**, British Gas Publication **IM/11**, "Flues for Commercial and Industrial Gas-Fired Boilers and Air Heaters".

The following notes are intended to give general guidance only.

### 6.1 General Requirements

The Hamworthy Purewell series of boilers are designed to be used with natural draught flues. Flue systems should be designed in accordance

with current regulations and with reference to the British Gas publication **IM/11** "Flues for Commercial and Industrial Gas Fired Boilers and Air Heaters". The following points should be noted: -

- 1) Each boiler **MUST** have its correct draught diverter fitted in an unmodified condition before connection to the flue system.
- 2) The bottom of the flue header should be at least 500 mm above the draught diverter skirt bottom.
- 3) The flue system must be self-supporting in the correct position to avoid compression of the draught diverter and enable its removal for boiler cleaning.
- 4) Boilers should be located as near the chimney as possible the nearest being not more than 2m (6ft) away.
- 5) The flue system should be designed to achieve a negative suction at all times at the draught diverter outlet on all modules in a bank. For optimum performance, draught conditions should be between -0.05 to -0.125 mbar. In the case of a single boiler installation the minimum vertical flue height is 2m above the draught diverter skirt. For multiple boiler installations consult Hamworthy Heating Technical Department. In some instances, mechanical assistance may be necessary. The boilers are suitable for connection to a fan diluted flue system, refer to British Gas publication **IM/11** "Flues for Commercial and Industrial Gas Fired Boilers and Air Heaters".
- 6) Purewell boilers are suitable for installation in a balanced compartment in accordance with the requirements of **BS 6644**. Consult Hamworthy Heating Technical Department for help or assistance if in doubt.

### 6.2 Design Waste Gas Volume and Temperature

It is recommended that the volume and temperature of the waste gases used for design of the flue system be as shown in Figure No. 1.

### 6.3 Flue Condensation

Care should be taken to ensure that the flue is installed in such a way that any condensation produced on start up will drain away naturally.

### 6.4 Materials

Materials used for the flue system must be mechanically robust, resistant to internal and external corrosion, non-combustible and durable under the conditions to which they are likely to be subjected.

### 6.5 Disconnection

Draught diverter models are designed to enable the primary flue to be lifted clear of the boiler to ease disconnection. The flue must be correctly reconnected when servicing is complete ensuring locating bolts are securely fitted. See **Section 13: SERVICING** for further information.

## 6.6 Flue Discharge

The flue system must ensure safe and efficient operation of the boiler to which it is attached, protect the combustion process from wind effects and disperse the products of combustion to the external air.

The flue must terminate in a freely exposed position and be so situated as to prevent the products of combustion entering any opening in a building.

Where the flue diameter is less than 200mm (8") a terminal must be fitted. Where the flue is of a larger size consideration should be given to the fitting of a flue discharge terminal or grill to stop ingress of birds, etc.

## 6.7 Surface Temperatures

Combustible materials in the vicinity of the boiler and flue shall not exceed 65°C during boiler operation. The flue shall not be closer than 50mm to any combustible material, except where it passes through such material with a non-combustible sleeve when the air gap may not be less than 25mm.

## 6.8 Flue System Location

The flue system must not be placed or fitted where there is undue risk of accidental damage to the flue pipe or undue danger to persons in the vicinity.

**NOTE!** The flue **MUST** be self-supporting. Check that the flue and chimney are clear from any obstruction.

## 7.0 AIR SUPPLY

Detailed recommendations for air supply are given in **BS 6644**. The following notes are intended to give general guidance. In all cases there must be provision for an adequate supply of air for both combustion and general ventilation, in addition to that required for any other appliance.

### 7.1 Air Supply by Natural Ventilation

The boiler room must have, or be provided with, permanent air vents directly to the outside air, at high level and at low level. For an exposed boiler house, air vents should be fitted preferably on all four sides, but at least on two sides. Air vents should have negligible resistance and must not be sited in any position where they are likely to be easily blocked or flooded or in any position adjacent to an extraction system which is carrying flammable vapour. Grilles or louvres must be so designed that high velocity air streams do not occur within the space housing the boiler.

The air supplied for boiler house ventilation shall be such that the maximum temperatures within the boiler house shall be as follows:

- 1) At floor level (or 100mm above) = 25°C.
- 2) At mid-level (1.5m above floor level) = 32°C.
- 3) At ceiling level (or 100mm below) = 40°C.

Where both low and high level openings are used, the grilles shall have a total minimum free area of: -

Low Level (inlet): 540cm<sup>2</sup> plus 4.5cm<sup>2</sup> per Kilowatt in excess of 60kW total rated input.

High Level (outlet): 270cm<sup>2</sup> plus 2.25cm<sup>2</sup> per Kilowatt in excess of 60kW total rated input.

**Figure No 4 - Mechanical Ventilation Flow Rates**

Atmospheric Boilers	Flow rate per 1000kW total rated heat input	
	Inlet air (Combustion ventilation)	Extract air (ventilation)
	m <sup>2</sup> /s.	m <sup>2</sup> /s.
Volume	1.10	0.45

### 7.2 Air Supply by Mechanical Ventilation

Air supplied to the boiler room by Mechanical means should be as follows: -

- 1) Mechanical inlet and mechanical extract can be utilised providing design extraction rate does not exceed one third of the design inlet rate.
- 2) Mechanical extract ventilation with natural inlet ventilation **MUST NOT** be used.

**NOTE:** For Mechanical ventilation systems an automatic control should be provided to cut off the gas supply to the boiler, in the event of failure of air flow in either inlet or extract fans.

## 8.0 WATER CIRCULATION SYSTEM

### 8.1 General

The Purewell Cast Iron Boiler has a low water content and the requirements of minimum water flow are given in **Section 8.8: Minimum Water Flow Rates** and Figure No. 2. Recommendations for the water circulation system are given in **BS 6644** and **CP 342**. The following notes are of particular importance: -

- 1) In a combined central heating and hot water system, the hot water storage vessel must be of the indirect cylinder or calorifier type. The hot water storage vessel should be insulated preferably with not less than 75mm (3 in) thick mineral fibre, or its thermal equivalent.
- 2) Circulating pipework not forming part of the useful heating surface should be insulated to help prevent heat loss and possible freezing, particularly where pipes are run through roof spaces and ventilated cavities. Cisterns situated in areas, which may be exposed to freezing conditions, should also be insulated. Insulation exposed to the weather should be rendered waterproof.
- 3) Draining taps must be located in accessible positions which permit the draining of the whole system, including the boiler and hot water storage vessel.
- 4) Each boiler has one 2" BSP female flow and one 2" BSP female return tapping. Flow and return headers should connect boilers but sufficient length of connecting pipe should be allowed to clear the casing before connecting into the headers. The headers should be connected to the system in a "reverse return" arrangement (the water flow in each header is in the same direction) to ensure equal flow in each module. Figure No. 8 shows typical layout.

### 8.2 Pressure Relief Valve (Safety Valve)

Each boiler, or in the case of a modular installations, each bank of boilers, must be fitted with a pressure relief valve to **BS 759** or **BS 6759** Part 1(**ISO 4126**) and sized as shown in **BS 6644**.

**BS 6644** provides comprehensive information for the selection and location of safety valves and attention is drawn to the higher capacity requirements of safety valves for pressurised hot water systems.

### 8.3 Open Vent and Cold Feed Pipe (See **BS 6644** for further information.)

Every boiler or group of boilers should have an open vent pipe and cold feed pipe installed between the boiler and the first water isolating valve. The minimum bore (mm) of these pipes per installation is as follows:-

Boiler Output	Feed	Vent
< 60kW	19	25
60kW - 150kW	25	32
150kW - 300kW	32	38
300kW - 600kW	38	50

The vent pipe must rise continually, it must not be valved except by a design which when closed for maintenance ensures the boiler is open to atmosphere. The pipe shall be protected against freezing where this might occur.

### 8.4 Altitude Gauge (Water Pressure Gauge)

Every boiler or group of boilers should be provided with a gauge complete with isolating cock. See Figure No. 8 for typical position.

### 8.5 Thermometer

See Figure No. 8 for typical position. A thermometer complete with pocket should be fitted in the pipework to indicate water flow temperature.

### 8.6 Drain Valves

Each boiler should have a 1/2" NB drain valve (not H.H.L. supply) fitted to drain the boiler only. The heating system in total should have drain valves as recommended by **BS 6644**. See Figure No. 8 for recommended positions.

### 8.7 Circulating Pump

One or more circulating pumps will be required to circulate water around the boilers and heating system. Figure No. 1 shows the hydraulic resistance of the boiler. The pump should be sited to facilitate servicing. It is important to note that when Purewell boilers are used to replace boilers on an existing system, the pumps should be checked for performance against the new boiler waterside pressure drop to ensure that the minimum flow rate can be obtained. It is also important that the existing system be flushed through twice to remove any loose matter, which may have accumulated. If in any doubt regarding the cleanliness of the system, a coarse filter should be fitted in the return pipework to the boilers.

### 8.8 Minimum Water Flow Rates

Minimum water flow rates are shown in Figure No. 2. These flow rates should be maintained through the boiler at all times whilst the boiler is firing. If the water flow rate is allowed to fall below the minimum, the boiler heat exchanger could fail due to the resultant scale formation. Particular attention should be paid to the restriction of external flow circuits during periods of low heat demand.

## 8.9 Water Pressure Drop

The waterside hydraulic resistance (Pressure drop) is shown in Figure Nos. 1 & 2.

**NOTE:** If boilers are run off time clock control, a pump overrun (not H.H.L. supply) should be fitted which must run for a minimum of 5 minutes on shut-down of the last boiler.

## 8.10 Control Schemes

### 8.10.1 Temperature Controls

An adjustable control thermostat is supplied for each boiler and should be set to operate within the range 65-90°C for standard applications.

If a higher water temperature is required (and providing sufficient head on the water system is available) the thermostat may be adjusted to operate up to 100°C. A temperature limiter, (hand reset limit thermostat) is also fitted to the boiler and is normally set at 100°C. The minimum difference between control thermostat and temperature limiter **MUST NOT** be less than 10°C.

### 8.10.2 Water Flow Controls

Any external mixing valves or similar controls should **ALWAYS** ensure that the minimum water flow rate shown in Figure No. 2 is maintained.

### 8.10.3 Frost Protection

Consideration should be given to fitting a frost thermostat set at approximately 4°C

## 8.11 Unvented Pressurised Systems

See Figure No. 8 for typical layout of a pressurised (Unvented) Hot Water System.

In order to correctly size a pressurisation unit for any heating system certain parameters are required. These are: -

- 1) Static height of highest component in system.
- 2) System volume - if not known a general rule of thumb of 10 litres/kW installed boiler power can be used.
- 3) Maximum flow temperature, i.e. most systems run at 82°C.
- 4) Maximum system hot working pressure, generally given in barg.

From the above information Hamworthy Heating can size the pressure unit and also the expansion vessel required.

Care must be taken in sizing expansion vessels to ensure maximum acceptance factors are not exceeded. Normally manufacturers of vessels impose a limit of 0.5. This value must not be exceeded at any time during the operation of the boiler: this includes the over pressure condition should a safety valve lift.

Consideration should also be given to sizing of the safety valve(s) in the system. See **BS 6759: Part 1 (ISO 4126)** for information.

See also **BS 6880: Part 1** for design considerations.

## 8.12 Modular Boiler Control Schemes

For Modular applications Hamworthy Heating can supply a unique boiler management control system called the 'Marshall'. This system comprises: a master control unit, which houses the main interface processor and, dependent on the number of boilers, a slave unit for each of the other boilers. Each unit plugs into the previous one by a low voltage signal wire. All the sensors are connected to the last 'slave' by a single cable, which is simple to attach. Both master and slave(s) are incorporated into the control fascia for ease of application. For further information contact Hamworthy Heating for details.

## 9.0 ELECTRICAL SUPPLY

### **WARNING: THIS APPLIANCE MUST BE EARTHED.**

Wiring external to the boiler must be installed in accordance with the IEE Regulations and any local regulations, which apply. Wiring must be completed in heat resistant 3-core cable. (Size 1.0mm<sup>2</sup> csa). Boilers are normally supplied suitable for 230 volts, 50Hz. Fascia fuse rating is 2A. External fuses should be 6A for all single boiler sizes.

The method of connection to the mains electricity supply must facilitate complete electrical isolation of the single boiler/battery with a contact separation of at least 3mm in all poles.

**This appliance must be isolated from the mains electricity supply in the event of electric arc welding being carried out on any connecting pipework.**

A mains isolator must be provided adjacent to the boiler in a readily accessible position. The supply should only serve the boiler. **NOTE!** Volt free contact electrical supplies must also be isolated when fitted (see note on fascia). Further details regarding connection to the electricity supply are given in **BS EN 60335, Part 1** or **BS 3456, Part 201**. The power supply should not be switched by a time clock, especially if a single header pump kit is utilised. The Purewell boiler has a remote stop/start loop which can be used to operate the boiler(s) under a timed regime. This remote loop requires a volt free contact for operation. Power is supplied by the boiler for this circuit to function. The voltage will therefore be the same as the boiler's power supply. Refer to Figure No. 10 for typical site wiring connections. See **BS 6644** for further information. Do not modify this circuit in any way. See Figure No. 12 for note re: External wiring.

## 9.1 Site Wiring

Access to the controls is achieved by rotating the ¼ turn latch and removing the door. A 20mm dia. knockout is provided in each side panel if required for electrical connections. Any other routing of site cables should ensure that cables do not pass close to the boiler flue hood or that any cable trunking does not interfere with normal air circulation and supply ducts.

A gland plate is supplied with every Purewell boiler having two 20mm dia. holes for electrical cable anchorage. A plug and socket arrangement is utilised for the site terminal connections. Care must be taken to ensure correct connections are made to the relevant terminals before applying power.

Refer to Figure Nos. 13 & 13a for typical wiring diagrams of standard fully automatic boiler.

## 10.0 BOILER ASSEMBLY AND INSTALLATION

### 10.1 General

Each boiler is despatched to site as follows: -

- i) Heat exchanger & basket including burners and gas valve(s) etc. on a pallet.
- ii) Casing complete with assembly instructions.
- iii) Control assembly with relevant control system.
- iv) Primary flue & draught diverter. (Draught Diverter models only)

Further details of each individual assembly are given below: -

**1) Factory tested heat exchanger casting assembly complete, including insulation wrap, gas valve assembly including pre-wired plug assembly. The gas connection pipe should be fitted to the boiler flue hood once the heat exchanger is in place. NOTE! Care must be taken to ensure no damage occurs to either insulation wrap or gas connecting pipe. THIS PIPE MUST NOT BE USED TO MANOEUVRE OR POSITION THE BOILER. NOTE! Consideration must be given to the weight of the boiler (See Figure No. 9), before lifting. It is recommended that the boiler is moved complete with pallet and positioned correctly. The pallet can then be dismantled and the boiler slid into position.**

**2) Casing including all screws, fasteners etc. to permit site assembly. Instructions are included in each box to show method of assembly. Two sizes are manufactured these are: - Small casing for boilers up to 80kW (NOTE! P70 L/L utilises larger casing), large casing for boilers from 95kW to 120kW. NOTE! When installing a multi-casing set the spacing plates must be used to correctly space the boilers approx. 3mm apart prior to fitting the casing. (See label attached to the basket fixing.)**

It is recommended that all mechanical work is carried out prior to fitting the casing assembly, this will reduce possible damage to the panels.

The casing assembly includes a component list, which is also shown in Figure No. 7. You should check to ensure that all parts are supplied prior to assembly.

**3) Controls assembly including fascia panel and thermostats. This assembly will be suited to the desired controls and include any optional extras required. Refer to Figure No. 7 for fitting instructions. Ensure all thermostat capillaries are inserted and correctly located into the top of the boiler. The controls assembly also incorporates a socket which matches the gas valve wiring plug. Care must be taken to ensure both plug and socket are correctly located and fixed in position by the screws provided.**


**4) (Standard Diverter models only) Primary flue pipe and draught diverter complete with casing bezel. Instructions are supplied with the draught diverter on how to assemble the unit, if required. These instructions MUST be followed correctly and fully complied with to ensure correct operation.**

**NOTE! Ensure the baffle (Not fitted to 120kW boiler) is positioned correctly and laying flat on the heat exchanger before fitting the flue hood onto the boiler (if removed).**

### 10.2 Heat Exchanger Insulation Fitting Instructions


With reference to Figure No. 5a - Unfold blanket and offer up to the boiler as shown. Ensure gas pipe cutout is positioned to the left and that the 'petals' are uppermost. Sit the insulation blanket onto the basket ensuring a snug fit.

**Figure No. 5a**



Reference to Figure No. 5b - Insulation should be folded around boiler such that its rear edges meet in the centre. Ensure flow and return connections are clear and unobstructed. Apply foil tape down join.


**Figure No. 5b**



Reference to Figure No. 5c - Fold down petals as shown. Use foil tape to affix edges. Fold as

required. Ensure gas pipe bracket is clear and unobstructed.

**Figure No. 5c**



Ensure combustion air passages are unobstructed when fully fitted.

### 10.3 Gas Pipe Fitting Instructions

With reference to Figure No. 6a - Remove half union and gas valve from gas train. Ensure gas valve/manifold bracket does not suffer undue stress/movement. Affix half union and gas valve assembly to gas pipe as shown using proprietary sealing compound. Ensure gas valve lever is correctly orientated. Offer gas pipe to boiler as shown. Bracket should be mounted as shown. Bracket's position will be dependent on boiler size.

**Figure No. 6a**




Figure No. 6b shows the pipe clamp fitted to Purewell 60, 70, 80 and 120 kW boilers.

**Figure No. 6b**





Figure No. 6c shows the pipe clamp fitted to Purewell 40, 50, 95 and 105 kW boilers.

**Figure No. 6c**



Tighten screws ensuring 'U' clamp threads do not damage insulation. It may be necessary to remove the bottom thread of the 'U' clamp with the bracket in lower position as it may foul the draught hood. Ensure no undue stress is placed on the gas pipe/manifold and ensure pipe is vertical/horizontal before clamping in position.

#### 10.4 Connection of Boilers to the Flue System.

Notes on the recommendation for design of the flue system are given in **Section 6:FLUE SYSTEM**.

##### 10.4.1 Standard Diverter models: -

When supplied with a draught diverter, it must be fitted to the boiler as supplied, **NO** modifications are permitted on site. Prior to fitting the assembly to the boiler, the top casing panel should be removed from its packing and placed in position. Fitting this panel after the flue is fitted is not recommended. Care should be taken to ensure the seal between primary flue pipe and boiler spigot is sound as a leak may affect the boilers' operation.

##### 10.4.2 Low Line models: -

The Low Line model incorporates its own draught diverter and care must be taken to ensure the seal between the outlet spigot and flue pipe is sound to avoid the escape of flue gas.

**10.2.3** The top panel will require protecting to ensure no damage occurs to the plastic coating during subsequent site assembly of other components. It is important, for service requirements, that the flue system is fully self-supporting. Check the flue and chimney are clear from obstruction.

#### 10.5 Gas Connection

The Purewell boiler is supplied with a gas pipe which when assembled exits the casing at the rear, see Figure No. 9 for position. The incoming mains gas supply must be capable of supplying gas to the boiler at the required pressure, under all firing conditions. For sizing information see Figure No. 11. An approved isolating valve & union should be installed for each boiler in a convenient and safe position and be clearly marked.

#### 10.6 Water Connections

See Figure No. 9 for position of water connections (flow and return). A 1/2" BSP plug is fitted local to the return connection for the fitting of a drain cock, **NOTE!** (Not HHL supply). Care must be taken when installing water system pipework that undue stress is avoided on the boiler flow and return connections. It is recommended that unions are fitted local to the boiler to permit future servicing requirements.


Fully closing valves must not be connected to both flow and return pipes unless the boiler is fitted with an individual, correctly sized safety valve. It is recommended that a 3-way 'L' port valve is fitted in the flow connection to allow an open vent situation should the boiler need to be fully isolated from the system.

#### 10.7 Casing and Controls Assembly

For assembly of casing components and controls unit see Figure No. 7.



Figure No. 7a - Exploded View of Casing Set.



## **11.0 COMMISSIONING AND TESTING**

### **11.1 Electrical Installation**

A suitably competent person **MUST** check wiring. Normal supply required is 230 volts AC, single phase, 50 Hz. An isolator correctly fused at 6A should be sited close to the boiler.

Access to the controls is achieved by rotating the \_ turn latch and removing the door. Connections to the boiler should pass through the 2 x 20mm wiring gland plate. If a single header pump kit is used then this power source must be constant and not switched by any time clock. The boiler is supplied with a remote stop/start circuit for time clock operation. **Any other interlocks, i.e. Pressurisation unit, BEM System should be wired in series with the remote stop/start loop.**

The site wiring terminal rail is marked with Live, Neutral and Earth connections. See Figure No.10 for details. **IMPORTANT READ THE WARNING NOTE REGARDING EXTERNAL VOLTAGES.**

This rail is of the plug/socket type and can be unplugged for wiring if required.

Schematics of the electrical control circuit(s) are shown in Figure Nos. 13 & 13a.

### **11.2 Gas Installation**

For design see **Section 5: GAS SUPPLY.**

The whole of the gas installation including the meter must be inspected and tested for soundness and purged in accordance with the recommendations of **BS 6891** or **IM/2** or **IM/5** as appropriate.

### **11.3 Water Circulation System**

For design see **Section 8: WATER SYSTEM.**

The system should be thoroughly flushed out with cold water without the pump in position. Ensure all the valves are open.

With the pump fitted the system should be filled and air locks cleared. Vent the radiators and check for leaks.

If the system is unvented the pressurisation unit should not be utilised for the initial filling. This should be carried out using a WRC approved double check valve and temporary-filling loop.

In order to comply with local Water Authority Regulations, this loop must be disconnected when filling is complete. Water treatments should not be fed through the pressurisation unit unless permitted by the manufacturer.

Check the expansion vessel cushion pressure as detailed by the manufacturer's Installer's Guide.

## **11.4 Commissioning the Boiler**

Before attempting to commission any boiler, ensure that personnel involved are aware of what action is about to be taken and begin by making the following checks: -

**1) Flueway passages to chimney are clear.**

**2a) Standard Diverter models: -** If necessary, remove the flue hood and baffle (not fitted to the 120kW boiler) to ensure the boiler flueways are clear. Reposition the gas baffle ensuring that it is laying flat on the top section. Re-fit the flue hood. Ensure boiler draught diverter passages are clear and clean.

**2b) Low Line models: -** The low line draught diverter incorporates an integral inspection cover. To gain access, remove insulation and M6 bolts on the sloping front of the hood assembly. This will reveal the inner part of the boiler, if further access is required, remove primary flue pipe (ensure it is correctly supported), and remove complete top of the draught diverter assembly. After cleaning the boiler re-assemble draught diverter in reverse of dis-assembly. Ensure all joints are correctly sealed.

**3) Adequate ventilation as per Section 7: Air Supply** exists in the boiler house.

**4) The system is fully charged with water, ready to receive heat.** All necessary valves are open and the pump is circulating water.

**5) The pipework and valve arrangement is installed to Hamworthy Heating recommendations in such a way that water flow rates will be in accordance with Figure No. 1.**

**6) The gas supply pipework is clear of any loose matter, tested for soundness and purged to CP: 331/3.**

### **11.5 Boiler Checks Prior To Lighting**

**NOTE!** Refer to Figure No. 1 for maximum gas inlet pressure for normal operation. Information relating to propane firing can be found in Appendix 'A'.

**Note: -** All propane boilers are fitted with a low gas pressure switch (set at 20mbar). Should the gas supply pressure fall below this level, the boiler **will not** operate.

**1) Gas supply is connected but turned to the "off" position.** Any unions or fittings are correctly tightened, test points are closed, burners correctly positioned, injectors are in place (of correct size) and tight and that the ignition and probe leads are connected correctly. Ensure ignition assembly electrodes are not cracked or broken.

**2) Ensure electricity is connected and 2A fuse on boiler removed,** the plug/socket gas valve connection is correctly located and fully tightened with screws provided and that the thermostat bulbs are fully inserted into the boiler pocket. Reset temperature limiter by firmly pressing pin (in controls housing.)

3) Check setting of both temperature limiter and control thermostat. The temperature limiter is generally set at 100°C from the factory unless otherwise instructed. Set thermostat to required temperature (normally 82°C) and ensure limits are set on knob if required.

**NOTE!** Minimum temperature setting should not be less than 72°C to avoid condensation in the flue if a 22°C system temperature rise is used.

**NOTE!** It is generally recommended that the minimum return temperature to a non-condensing boiler is 50°C.

4) Drop down fascia on the controls housing to reveal the main terminal rail. Figure No. 12 shows the correct location of incoming wires. Remove link on terminals C1 and C2 (black wire) and insert a multi-meter set to read DC uA. Carefully remove high/low terminal link on terminals C3 and C4 (red/brown wire), this will ensure burner stays at light up rate (low fire) when fired.

5) The Purewell fully automatic boiler utilises a low fire start gas rate ignited by direct spark ignition (DSI), see Figure No. 14. To ascertain which type of gas valve is fitted and the method of low fire and high fire adjustment, refer to Figure No. 15. You should familiarise yourself with this procedure for use later when required.

6) If a single header pipe kit is fitted, the run on timer should be set to 5 minutes. Check that the fuse on pump terminal rail is fitted and sound.

### 11.5.1 Procedure for Initial Lighting

Ensure gas service cock is in the "off" position. Replace 2A fuse in fascia. Press lockout button on fascia to reset timer (wait at least 15 seconds before pressing again if lockout neon does not go out. After a delay the spark should be heard across the electrodes. As the gas service cock is closed, the controls should go to lockout after approximately 3 seconds (amber neon on fascia lit). If the above occurs correctly, open service cock and press reset button on fascia.

After a delay the ignition 'click-click' should be heard and the main gas valve should energise lighting the main burner. Turn the control thermostat to the required flow temperature. **NOTE!** The multi-meter should be reading at least 1µA.

### 11.6 Gas Pressure Adjustment and Combustion Checks

After the boiler has operated for approximately 10 minutes, remove the 2A-control fuse on the fascia. Open the pressure test point screw on the burner manifold and fit a manometer (suitable for 30mbar - Natural Gas or 50mbar - Propane). Check low fire (start rate) against pressure shown

in Figure No. 1 or Appendix 'A'. If necessary adjust low fire pressure (refer to Figure No. 15. for relevant gas valve fitted).

Replace high fire link carefully to drive valve system up to high fire. Check gas pressure against that shown in Figure No. 1 or Appendix 'A'. If necessary adjust high fire governor to suit. Occasionally this high fire adjustment can influence the low fire start rate, therefore remove link and check low fire pressure again. Adjust if required. Repeat until low and high fire pressures are as shown in Figure No. 1 or Appendix 'A'.

The Purewell boiler has been designed to conform with the requirements of the Gas Appliance (Safety) Regulations (1992). For Natural Gas the gas pressure governor control system is configured for a nominal gas inlet pressure of 20mbar with a maximum inlet pressure of 25mbar. Larger Purewell Automatic boilers (95, 105 and 120kW) are fitted with a unique flow share gas valve arrangement. Refer to Figure No. 16 to establish method of adjustment of the by-pass throttle arrangement. **NOTE!** The by-pass valve throttle **MUST** be used as a coarse adjuster, the main control **MUST** always be accomplished by the high/low control valve.

For Propane firing boilers, the nominal gas inlet pressure is 37mbar, with a maximum inlet pressure of 47mbar. All Propane firing boilers are fitted with a low gas pressure switch (set at 20mbar). Should the gas supply pressure fall below this level, the boiler **will not** operate. All Propane firing boilers are fitted with a single gas valve providing high and low control. Refer to Figure No. 15.

Remove manometer and close pressure test point. Record all readings for future reference on relevant commissioning sheet.

Check no flue gas spillage occurs from the diverter: Ref. **BS 5440**: Part 1 will give guidance if required. Allow system to warm up sufficiently to check operation of control thermostat.

### 11.7 Temperature Limiter (Limit Thermostat)

Check temperature limiter setting. Removing plastic cover (unscrewing) can achieve this if fitted. Undo holding nut and withdraw into the controls housing. Adjust if required and replace in reverse order to above.

A combustion check must be taken when first commissioning the boiler. A sampling point is provided in the flue on draught diverter models or inspection door on Low Line models, which is covered by a small push in plug which can be removed. **NOTE!** Care should be exercised if the boiler is firing as the flue can achieve temperatures, which will produce injury if touched.

Combustion figures for Natural Gas should be as follows: -

CO<sub>2</sub> = 9% volume in dry flue gas  
CO = 0-50ppm: however figure should not exceed 200ppm under normal operating conditions.

Details of flue gas composition relating to propane firing can be found in Appendix 'A'.

### 11.8 Safety Checks

To check for correct operation of the controller, remove A link (Terminals C1 and C2): the boiler should lockout after approximately one second. Check that the flame has been extinguished. Remove multi-meter and replace wire link (Terminals C1 & C2). Wait at least 15 seconds before pressing re-set button on fascia to re-set controller. After a waiting period the boiler will light and run normally.

### 11.9 User's Instructions

When the above is complete, the boiler owner or their representative should be made aware of the lighting and operating instructions fitted to the inside of the boiler door. A practical demonstration should be given describing each functional step. This Installer's Guide and User's Instructions should then be handed over and be kept in a safe place for easy reference.

## 12.0 FAULT FINDING

### 12.1 Safety Features Summary

Should the control thermostat fail, the temperature limiter will trip thus creating an immediate shutdown regardless of firing mode. An overheat neon on the controls fascia will indicate this condition has occurred. The door will have to be removed to permit access to the temperature limiter re-set pin. If, after pushing the pin in, the light on the fascia does not go out and the boiler does not light up, it could be that the boiler is still too hot, i.e. the control thermostat has not re-set. An investigation should be carried out to ascertain the reason for the overheating. An obvious reason would be too low a water flow rate through the boiler.

The flame is under constant supervision by the burner logic controller. This is accomplished by measuring the flame's ability to rectify an AC current. If the flame diminishes for whatever reason and the rectified current drops below the controllers minimum (Honeywell controller minimum detection current is 0.7uA DC), the controller will induce a non-volatile lockout which will require a manual re-set (situated on the controls fascia) to re-start the control sequence. If the boiler continues to lockout, then an investigation must be made to ascertain the cause. See Figure No. 17 for possible corrective scenarios.

All Propane firing boilers are fitted with a low gas pressure switch (set at 20mbar). Should the gas

supply pressure fall below this level, the boiler **will not** operate.

### 12.2 Fault Finding Procedures

General fault finding is shown in Figure No. 17. If the boiler still cannot be operated satisfactorily after following the chart, consult your local office of Hamworthy Heating for assistance.

### 12.3 Possible Causes of Boiler Lockout

- 1) Ignition failure due to no spark at electrode.
- 2) Ignition failure due to faulty gas valve.
- 3) Ignition failure due to broken igniter electrode or probe lead.
- 4) No or low gas supply pressure.
- 5) No ignition due to faulty controller.

## 13.0 SERVICING

**13.1** Regular annual servicing is recommended to ensure trouble free operation. Although cleaning of flueways may not be necessary on a yearly basis, it is important that all controls and safety features are checked for correct operation. **NOTE!** Measuring flue gas CO<sub>2</sub> and gas temperatures will give an indication of the state of the boiler flueways and waterways. Results should be compared with previously measured values to establish possible loss of efficiency.

**13.2** Before servicing the boiler, the following procedure must be carried out: - **WARNING: Isolate the electrical supply and turn off the gas service cock to the boiler module being serviced.**

- 1) Remove the front casing door by using a screwdriver to rotate the 1/4 turn latch.
- 2) Turn off gas service cock, (fitted upstream of gas control valve).
- 3) Undo both screws on gas valve wiring plug, situated under controls assembly, and disconnect plug completely by pulling firmly downwards.
- 4) Disconnect igniter and probe leads carefully. (Protective boots will require pulling back to reveal connectors.)
- 5) Slacken union below gas service cock and release. Slacken and remove nuts/washers holding gas valve and manifold assembly. Remove manifold assembly taking care not to damage high/low gas solenoid.
- 6) Carefully remove burner assembly by pulling burner front plate. Check condition of igniter assembly and probe for damage. Clean as required. Check burner bars and clean using a soft brush if required (if possible use compressed air to blow out the dust inside the bar). Damaged or cracked burner bars should be replaced. To replace an individual bar will require drilling out the rivets holding it on to the front plate. A replacement burner bar will be supplied with clinch nuts and screws to fix onto the front plate.

The boiler flueways can now be cleaned as follows:-

### 13.3 Standard Diverter models: -

1) Check the flue above the draught diverter is self-supporting before removing the two bolts on the draught diverter clamp and sliding the primary flue up inside the double cone assembly. The complete assembly can be removed and stored safely. Lift flue bezel and remove the top-casing panel by removing the relevant screws. Lift off and store in a safe place to avoid damage or scratching.

2) Undo the screws supporting the gas pipe clamp. **NOTE!** The boiler gas pipe may require supporting in order not to place undue stress on the main gas header pipe.

3) Carefully prise away the silver insulation jacket from the flue hood. Undo and remove the nuts holding the flue hood to the boiler. Take care not to move the locking nuts which locate the hood's position. Remove the gas baffle, (not fitted to 120kW boiler).

### 13.4 Low Line models: -

1) Check the flue above the flue pipe is self-supporting. Remove the top panel to gain access to the draught diverter. Remove the insulation and inspection cover (M6) bolts on sloping front.

2) If further access is required remove M6 bolts along top of draught diverter. The top section should now drop down to free the flue pipe. Undo M6 bolts from baffle and swing away.

3) **NOTE!** This baffle **MUST** be relocated in the correct position when re-assembling the draught diverter.

4) **All models: -** The boiler flueways are now exposed and can be brushed through diagonally in both directions to remove deposits from the cast iron finned surfaces. Re-assemble the boiler in the reverse order to that shown above. Ensure a new rope seal is fitted to the flue hood to maintain a gas tight seal, (see spares list). Ensure primary flue is sealed into flue hood spigot. The boiler's operation may be affected if this seal is not completely fitted. Before replacing the burner bar assembly, lift out both halves of the radiant reflector and brush off any dust and fallen deposits accumulated on it. Also clean the area under the reflector before re-placing it in its correct location. Re-assemble the burner bar assembly, ensuring correct location on the rear support bracket. Refit the gas manifold taking care not to damage any fragile components. Check all gas connections are tightened securely before opening the gas service cock. Switch on the electricity supply and re-light the boiler following the correct procedure on the inside of the door.

Take gas pressure readings and exhaust gas readings and compare with Figure No. 1, or for propane firing refer to Appendix 'A', adjust as required. Ensure no gas leaks are evident from the gas connections, see Figure No. 3 for procedure. Check thermostat settings and adjust if required.

Re-fit door and tidy floor around boiler as necessary.

## 14.0 REPLACEMENT OF FAILED COMPONENTS

There are a number of components listed below which can be replaced simply and quickly by following the given procedure. In each case carrying out the appropriate part of the commissioning procedure must check the operation of each replaced component. See **Section 11.0:Commissioning and Testing**

**NOTE: Isolate electrical supply to the boiler and turn off the gas supply before removing controls cover and commencing any servicing or component exchange procedure.**

### 14.1 Igniter Assembly

Reference to Figure No. 10 shows position of igniter assembly. To remove assembly the igniter lead must first be disconnected from the electrode, (Protective boot to be pulled down cable to reveal connector).

Figure No. 14 shows diagram of igniter assembly and relevant components and part numbers. Renew components as required and generally remove any loose sooty deposits and clean as required. Ensure positions of components are as recommended in Figure No. 14 (ensure protective boot is replaced over electrode).

### 14.2 Control Thermostat Renewal. Part No. 339009345 or 533901178

Alternative thermostat manufacturers may be used in the Purewell boiler controls assembly. However, the fitting and wire spade connections are physically identical. The terminal identification may well be different from that shown on the wiring diagram inside the fascia. Please refer to thermostat to ensure correct connections are made and correct operation is obtained.

To replace the thermostat the following procedure must be followed. **NOTE!** Record existing temperature setting of thermostat for reference before removal. Remove holding screws underneath and lift boiler top panel to reveal thermostat pocket. Carefully remove thermostat phials. Drop down fascia to reveal controls section. Remove the 'push on' spade connectors from the thermostat body noting position of coloured cables. Pull off the control knob and remove bezel. (Note! The two M3 screws holding the thermostat to its bracket may retain this). Note if screws are of different type/length for re-assembly purposes before removing them. The thermostat body can now be removed by gently feeding capillary through the controls bulkhead. Fit the new thermostat and ensure the capillary is correctly located within the pocket. Do not force the bulb into the pocket by placing undue stress on the capillary. Close fascia and re-fit top panel correctly.

Run the boiler and turn the thermostat up and down to check for correct operation. Set thermostat to previously noted setting.

#### **14.3 Temperature Limiter (Limit Stat) Renewal Part No. 339011044 or 533901179**

The temperature limiter renewal procedure follows that of the control thermostat with some minor differences. These are as below: -

Remove the 'push on' spade connections from the temperature limiter body noting position of coloured cables. Remove plastic cover (if fitted) and unscrew holding nut to detach temperature limiter from housing. Gently feed the capillary back through the controls bulkhead. Re-set temperature limiter to 100°C. Re-assemble temperature limiter into controls housing ensuring correct cable notation. Refer to the thermostat diagram if terminal identification differs from those given in Figure Nos. 13 & 13a, (Boiler schematic wiring diagrams).

#### **14.4 Main Gas Valve.**

**NOTE!** Some gas valve components can be replaced without completely removing the whole assembly from the boiler. However, Hamworthy Heating strongly recommend that a new gas valve assembly is fitted to ensure safe, reliable operation of the boiler. Please refer to Hamworthy Heating Technical Department before attempting to remove components from the gas valve. **NOTE!** Only gas valves with an identical Type No. may be used for replacement. Please contact Hamworthy Heating spares Dept. for further information.

Various types and manufacturers of gas valves are used. Refer to Figure No. 15 for particular valve(s) fitted.

- 1) Ensure power and gas supplies are isolated.
- 2) Remove the gas valve wiring plug from the socket in the controls housing by un-doing both screws and pulling firmly downwards. Undo the union connection and 8mm nuts holding the gas valve/manifold assembly to front plate, this will allow the whole assembly to be removed from the boiler.
- 3) Remove the gas valve by unscrewing cap head screws holding valve to pipework. **NOTE!** The position of the relevant electrical cables should be noted, especially on the 95-120kW boilers. When replacing the gas valve, it is advisable to renew the 'O' ring seals sealing both ends. See **SECTION 15.0 Recommended Spares** for Part Nos. Note that the 'O' ring fitted to the 40-80kW (Natural Gas) and all propane models, is different to that used on the 95-120kW (Natural Gas) models. Do not over tighten cap head screws in gas valve body. Ensure electrical plugs are firmly and correctly located and holding screws are tightened.
- 4) Replace assembly ensuring correct orientation of the gas valve. Ensure that the gas flow is in the same direction as the arrow on the bottom of the valve. Refit all external components and replace plug into controls housing socket, re-fit and tighten screws holding plug to housing. Switch on gas and power supply and check for integrity of all joints using a proprietary leak detector.

Ensure gas valve(s) operation is correct and safe before continuing. Refer to Figure No. 3 if necessary for valve integrity check procedure.

- 5) Re-light the boiler using instructions on the inside of the door. Check and adjust, the low fire/start gas and high fire gas pressures, refer to Figure No. 1 for Natural Gas or Appendix 'A' - propane firing, for correct settings. Re-set throttle valve position, if replaced, see Figure No. 16 for procedure.

If necessary, refer to **Section 11.4 Commissioning the Boiler**, for correct procedures.

## **15.0 RECOMMENDED SPARES**

**Please Note!** To ensure the correct spare parts are despatched by our spares department, it is imperative that the complete Boiler/Control Panel Serial numbers are given. The Boiler Serial Number is located on the gas manifold inside the door. The Control Panel Serial Number is located inside the Control panel on the maximum power-rating label. These numbers **MUST** be quoted when ordering spare parts.

<b>SPARES ITEM</b>	<b>PART NO.</b>
<b>Electrical Items</b>	
2 Amperes Control Fuse.....	747225834
6.3 Amperes Pump Fuse.....	747225842
Green Neon.....	533901031
Amber Neon.....	533901030
Red Neon.....	533901029
Reset-button.....	533901132
Hours Run Meter.....	533901067
Ignition Sequence Controller.....	533901169
230 Volt VFC Single Pole Relay.....	533901204
<b>Mechanical Items</b>	
Single Burner Bar.....	533301003
Heat Exchanger Nipple.....	330502033
Flue hood thermoseal Yarn (10mm Dia.).....	331299233
Injector Copper Washer.....	339008347
Gas Valve 'O' Ring Joint (40 - 80kW only).....	742111245
Gas Valve 'O' Ring Joint (95 - 120kW only).....	742122069
Spark Electrode.....	533805005
Probe Electrode.....	533805004
Control Thermostat.....	533901178(Imit)
“ .....	339009345(L&G)
Temperature Limiter.....	533901179(Imit)
“ .....	339011044(L&G)

**NOTE! For any service/replacement parts (Especially Gas Valves) the boiler Serial No. (on Data Plate inside boiler) MUST be quoted.**

For service or spares please contact: -

**Hamworthy Heating Ltd.  
Fleets Corner  
Poole  
Dorset BH17 OHH  
Phone No. 01202 662500  
Fax No. 01202 665111**

Figure No 8 - Boiler Installation (Typical)

Key: t - Thermometer or sensor  
p - Pressure Gauge







Figure No. 10 - General Layout (Front View)



**Figure No. 11 - Gas Flow in Pipes**

Purewell Boiler Output	Maximum length of gas pipe (Metres)						
	¾" dia.	1" dia.	1½" dia.	2" dia.	2½" dia.	3" dia.	4" dia.
40kW	10	42	-	-	-	-	-
50kW	-	25	180	820	-	-	-
60kW	-	16	120	540	-	-	-
70kW	-	11	85	380	-	-	-
80kW	-	-	62	280	900	-	-
95kW	-	-	42	185	580	-	-
105kW	-	-	33	145	470	-	-
120kW	-	-	25	110	345	-	-
160 (2 x 80kW)	-	-	12	56	180	-	-
190 (2 x 95kW)	-	-	-	38	120	750	-
210 (2 x 105kW)	-	-	-	30	96	600	-
240 (2 x 120kW)	-	-	-	22	72	440	-
285 (3 x 95kW)	-	-	-	15	47	290	-
315 (3 x 105kW)	-	-	-	11	37	235	-
360 (3 x 120kW)	-	-	-	-	27	170	810
380 (4 x 95kW)	-	-	-	-	24	150	730
420 (4 x 105kW)	-	-	-	-	19	115	570
480 (4 x 120kW)	-	-	-	-	14	86	430
525 (5 x 105kW)	-	-	-	-	11	71	340
600 (5 x 120kW)	-	-	-	-	-	51	245
630 (6 x 105kW)	-	-	-	-	-	46	220
720 (6 x 120kW)	-	-	-	-	-	34	165


The above table expresses pipe lengths from gas meter to appliance which will produce approx. 1mbar pressure loss. This table must be used in conjunction with losses of various fittings fitted in the gas line shown below.

Fitting Type	¾" dia.	1" dia.	1½" dia.	2" dia.	2½" dia.	3" dia.	4" dia.
Per elbow	0.5m	0.5m	1.0m	1.5m	2.0m	2.5m	3.5m
Per Tee	0.5m	0.5m	1.0m	1.5m	2.0m	2.5m	3.5m
Per 90° Bend	0.3m	0.3m	0.3m	0.5m	0.5m	1.0m	1.5m

For example: - 2 Purewell 120kW Boilers being fed by 2½" pipe with 6 elbows between gas meter and boiler header can have a maximum length of 72m - (6 x 2m) = 60 metres run to achieve a 1mbar loss.

**Note! Information above is based on IM/16.**

**Figure No. 12 - Purewell Boiler Site Wiring Diagram (Automatic)**



**NOTE!....Maximum rating of a volt free contact(s) is : 3 Amperes Resistive**

**WARNING! External voltage MUST NOT be applied to remote stop/start terminals 3 & 4 or high/low control loop terminals C3 & C4 or any terminals on the fascia.**

**NOTE! \* Volt free contacts may have separate supply. Ensure all power supplies are completely isolated prior to working on the electrical circuits of this appliance.**

Figure No. 13 - Standard Automatic Wiring Diagram Schematic




Figure No. 13a - Additional Wiring Schematic for Models Fitted with Pektron 0459 Series Ignition Controls




Figure No 14 - Diagram of Igniter Electrode/Probe Assembly





Figure No 15 - Diagram of Automatic Gas Valves.



**ADJUSTMENT PROCEDURE.**

Refer to Figure No. 1 to find the low fire/start and high fire gas pressures for the boiler being fired.

Fit a manometer (suitable for 30mbar) onto manifold test point.

Light the boiler, then remove the protective cover from the Hi/Lo pressure regulator.

To adjust the high fire gas pressure, turn the outer nut on the hi/lo pressure regulator.

To adjust low fire/start gas pressure, remove the link between terminals C3 and C4; nominally set the low fire/start gas pressure by rotating the inner cross-head screw, whilst keeping the outer nut from rotating. Turn the boiler off then on again and fine trim the pressure.

Insert or make high fire link on terminals C3 and C4; the boiler should now drive to high fire. Replace protective cap on Hi/Lo gas valve.

**Note! The low fire setting must always be set last of all. The valves operation may be incorrect if this omitted.**

**Note!** It is also advisable to carry out this procedure with all the boilers firing. The long-term reliability of the ignition system may well be reduced unless this procedure is carried out correctly.

**Figure No. 16 - Diagram of 'Hi' Flow Gas Valve Assembly (Natural Gas Only)**

**PUREWELL 95, 100 (L/L), 105 & 120kW Automatic & WARMWELL HE 140 Automatic.**

The 'Flowshare' gas valve assembly is designed to pass the correct quantity of gas at the nominal inlet pressure of 20mbar and a maximum inlet pressure of 25mbar.

Refer to Figure No. 1 to find low fire/start and high fire gas pressures for the boiler being fired.

Fit a manometer (suitable for 30mbar) onto gas manifold pressure tapping point.

Light the boiler. Remove protective cap from the Hi/Lo pressure regulator.

Turn the Hi/Lo valve high fire pressure regulator (outer nut) clockwise until the pressure stops increasing. Loosen Throttle locking nut (if fitted) and rotate the throttle valve adjuster screw until the manifold pressure is a approx. 0.5mbar greater than the required high fire gas pressure.

Tighten the locking nut (if fitted) on the throttle adjuster screw.

Turn the Hi/Lo valve high fire rate adjuster anti-clockwise to fine trim the high fire pressure.

Refer to Figure No. 15 for procedure on how to adjust valves for correct low fire/start gas pressures.

**NOTE! Honeywell valves shown in diagram.**




Figure No. 17 – Fault-Finding Procedures (Automatic Only)





Figure No. 17a – Fault-Finding Procedures (Automatic Only) (Cont.)



INFORMATION RELATING TO PROPANE FIRING

**NOTE!**

**LPG FUELS - IT IS STRONGLY RECOMMENDED THAT, ON LPG INSTALLATIONS, GAS DETECTION EQUIPMENT BE FITTED. THIS EQUIPMENT SHOULD BE POSITIONED NEAR THE BOILER AND AT LOW LEVEL. IT IS ALSO IMPORTANT THAT THE SPACE HOUSING THE BOILER IS ADEQUATELY VENTILATED AT HIGH AND LOW LEVEL. REFER TO MAIN INSTALLER'S GUIDE.**

**1.0 INTRODUCTION**

The operation of the Purewell range of boilers on LPG-Propane (3<sup>rd</sup> family)<sub>I<sub>3P</sub></sub> is similar to that on Natural Gas (2<sup>nd</sup> family)<sub>I<sub>2H</sub></sub> and the design and installation details described in the main body of the installer's guide should be followed. There are however, differences in the construction and setting of the propane-fired boiler which is as follows: -

a) The main gas injectors (located in the gas manifold) are replaced with those detailed the

Performance and General Data Information table below.

b) The nominal gas inlet pressure for propane should be 37mbar.

c) Relevant labels are replaced to indicate the appropriate gas for which the boiler is set up to fire.

The following tables and paragraphs, using the same numbering system as the main installer's guide, highlight the different values and procedures to be used when firing propane, and should be used in conjunction with the Main Installer's Guide.

**Performance and General Data Information**

GENERAL DATA	Model									
	40	50	60	70	80	95	100	105	120	
Boiler Input kW (Gross)	49.3	63.4	74.5	88.4	101.0	120.0	126.0	132.0	150.0	
Boiler Input kW (Net)	45.4	58.4	68.6	81.4	93.0	110.5	116.0	121.6	138.1	
Boiler Output kW	40	50	60	70	80	95	100	105	120	
Gas flow rate										
	m <sup>3</sup> /h	1.9	2.4	2.8	3.3	3.8	4.5	4.7	5.0	5.7
	kg/h	3.5	4.6	5.3	6.3	7.2	8.6	9.0	9.5	10.7
Gas manifold pressure	mbar	15	15	15	15	17	29	23	25	24
Start (low fire) manifold pressure (Auto only)	mbar	4.0	4.0	3.0	3.0	3.0	2.5	2.5	2.5	2.5
<b>FLUE DATA</b>										
Approx. flue gas temp ∞C		180	190	190	200	210	200	200	210	190
Approx. flue gas vol. @ 9% CO <sub>2</sub> & NTP. m <sup>3</sup> /h		68	83	81	97	110	132	147	147	175
CO <sub>2</sub> %		8.0	9.0	11.0	11.0	11.0	11.0	10.0	11.5	10.0
<b>GAS DATA</b>										
Nominal gas inlet pressure	mbar	37								
Maximum gas inlet pressure	mbar	45								
Injector marking/ Dia.	mm	2.1	2.3	2.6	2.8	2.9	2.4	2.7	2.7	2.9

**11.5 BOILER CHECKS PRIOR TO LIGHTING**

Ensure that the gas supply is connected but turned to the 'OFF' position. Remove the cover on the low gas pressure switch and connect a multi-meter across terminals 'C & NO' - to measure circuit continuity.

Connect a manometer suitable for 50mbar to the pressure tapping on the switch body and gradually turn 'ON' the gas supply. The switch should operate at approximately 20mbar - noted on the multi-meter.

Turn 'OFF' the gas supply and undo the pressure test point on the gas valve inlet and allow the gas pressure to fall. The switch should operate at approximately 20mbar - noted on the multi-meter.

**11.5.1 Gas Pressure Adjustment**

After approximately 30 minutes of normal firing, connecting a manometer to test point on the manifold should check the manifold gas pressure. Minor adjustments to the appliance governor may be necessary to correct for site gas pressure conditions.


**NOTE:** The above is a first order check. Final setting must be made using a gas meter.

### 11.5.2 Combustion Checks

A flue gas sampling point is provided in the front boiler casing (see Figure No. 7). To check combustion take a flue gas sample from each module test point and for reference CO<sub>2</sub> measurements should be between 8.0% and 11.5% or 9.0 to 4.0% O<sub>2</sub> (dependant upon model). Normal CO levels should not exceed 200ppm.


**NOTE:** All the above measurements refer to **dry flue gas** samples.

### Gas Pressure Switch Location




Key: I - Gas Pressure Switch  
II - Main Gas Valves

### Gas Pressure Switch - Wiring Schematic



### Gas Pressure Switch Adjustment



With the cover removed, turn the M3 nut clockwise to increase the set point and vice-versa. Seal the adjuster after setting.

### 15.0 RECOMMENDED SPARES

#### MECHANICAL ITEMS

#### PART No.

Low Gas Pressure Switch..... 339009477

THIS PAGE LEFT INTENTIONALLY BLANK

# Hamworthy Heating Accredited Agents

## ■ Central & South West England

### **Driver Engineering Limited**

778 Wimborne Road, Moordown

Bournemouth BH9 2DX

Tel: 01202 525140

Fax: 01202 536442

## ■ Scotland

### **McDowall Modular Services**

97a Hawthorn Street

Glasgow G22 6JD

Tel: 0141 336 8795

Fax: 0141 336 8954

## ■ North West England

### **Gillies Modular Services**

210-218 New Chester Road

Birkenhead

Merseyside L41 9BG

Tel: 0151 666 1030

Fax: 0151 647 8101

## ■ Northern Ireland

### **McCaig Collim Limited**

92-94 Dargan Crescent

Duncrue Industrial Estate

Belfast BT3 9JP

Tel: 01232 777788

Fax: 01232 776865

## ■ North East England

### **Allison Heating Products**

17 Beach Road

South Shields

Tyne & Wear NE33 2QH

Tel: 0191 455 7898

Fax: 0191 455 7899

## ■ Southern Ireland

### **HEVAC Limited**

70-72 Lower Dorset Street

Dublin 1, Ireland

Tel: 003531 830 1211






Fax: 003531 830 1990

**For all other areas, or for further advice, please contact Hamworthy Heating head office service department in Poole, telephone 01202 662500.**

# Hamworthy Heating

## Connect direct for better service

Direct Dial Telephone Numbers



**HAMWORTHY**  
heating products

### POOLE OFFICE

**HAMWORTHY HEATING LIMITED**

Fleets Corner, Poole, Dorset, BH17 0HH. England.

Main Switchboard tel: **01202 662500.**

Customer Services fax: **01202 665111.**

**Boilers ∞ controllers ∞ water heaters ∞ pressurisation sets ∞ cold water boosters**

**GENERAL ENQUIRIES** ..... ☎ **01202 662552**

For general enquiries on products and services available from Hamworthy Heating, our Customer Liaison staff are on hand to answer your questions.

**QUOTATIONS** ..... ☎ **01202 662552**

Hamworthy Heating provide an efficient pricing and quotation service. Our Customer Liaison staff will also be pleased to arrange for one of our Sales Engineers or Authorised Sales Agents, to visit you to discuss your needs in person, and offer expert technical and commercial advice on heating, flue and water systems.

**TECHNICAL ENQUIRIES** ..... ☎ **01202 662527/662528**

For problems of a technical nature and further product support, our Technical Applications Engineers offer specifiers and contractors advice on all aspects of equipment application, configuration and capability.

**ORDER ENQUIRIES** ..... ☎ **01202 662518**

For an efficient response to order acknowledgement and administrative queries, contact our order processing team.

**DELIVERY ENQUIRIES** ..... ☎ **01202 662515/662504**

Deliveries from Hamworthy Heating arrive direct from the factory on a vehicle equipped with a tail-lift for ease of off-loading to ground level. Our contracts team will progress despatch and liaise individual delivery arrangements.

**SPARE PARTS** ..... ☎ **01202 662525**

A comprehensive spare parts service is operated from our factory in Poole, providing replacement parts for both current and discontinued products. Please contact our spares team, providing details of product type, serial number, model and part requirements wherever possible.


**SERVICE DEPARTMENT** ..... ☎ **01202 662555**

At Hamworthy Heating we employ our own skilled service engineers who are trained to work on all of our products. Our National coverage of all UK mainland sites is supported by a network of Authorised Service Agents who can provide the same high level of service and product expertise.

**EXPORT** ..... ☎ **+44 (0)1202 662514**

Hamworthy Heating has an expanding global network of distributors and partner companies providing local contact, product and after sales service. This network currently includes Italy, Benelux, Germany, Baltic States, Finland, Russia, Poland, Australia, South Africa, Hong Kong and China.

### BIRMINGHAM OFFICE



**HAMWORTHY**  
flue products

**HAMWORTHY HEATING LIMITED**

Shady Lane, Great Barr, Birmingham, B44 9ER

Main Switchboard tel: **0121 360 7000.**

Customer Services fax: **0121 325 0890.**

**Flue components ∞ design service ∞ bespoke manufacture ∞ installation**

**FLUE PRODUCTS (ALL ENQUIRIES)** ..... ☎ **0121 360 7000**

Our factory in Birmingham offers a comprehensive range of flue products from stock, or alternatively provides a full design and installation service incorporating sizing, site survey and drawings for approval prior to manufacture.

Associate Companies, Offices and Agents throughout the World.

Hamworthy reserves the right to make changes and improvements which may necessitate alteration to the specification without prior notice.